

SEE DETAIL SPF-7 OR  
SPF-7A FOR OARAPET  
TERMINATIONS .

SPRAY POLYURETHANE  
FOAM (1" [25 mm]  
MIN. THICKNESS .

ELASTOMERIC  
COATING .

PARAPET WALL .

V-GROOVE SPF  
AT LOWER EDGE  
AND INSTALL  
ELASTOMERIC  
SEALANT

ALTERNATE

PROPERLY PREPARE  
METAL FLANGE  
BEFORE APPLYING  
SPF TO ENHANCE  
ADHESION

EXTEND ELASTOMERIC  
COATING ONTO  
SHEET METAL  
SCUPPER LINER  
2" [50MM] MIN.  
PAST EDGE OF SPF

SHEET METAL  
SCUPPER LINER

ROOF DECK  
PREPARE AS  
REQUIRED

### PRIMARY DRAINAGE SCUPPER AT PARAPET WALL

2001

NOT DRAWN TO SCALE

SPF- 21