

SEE DETAIL SPF-7 OR
SPF-7A FOR PARAPET
TERMINATIONS .

V-GROOVE SPF
AT LOWER EDGE
AND INSTALL
ELASTOMERIC
SEALANT

ALTERNATE

EXISTING ELASTOMERIC
ROOF COATING
CEMENTITIOUS TOPPING
SEALING PRIMER
NEW ELASTOMERIC
ROOF
COATING

PROPERLY PREPARE
METAL FLANGE
BEFORE APPLYING
SPF TO ENHANCE
ADHESION
EXTEND ELASTOMERIC
COATING ONTO
SHEET METAL
SCUPPER LINER
2" [50MM] MIN.
PAST EDGE OF SPF

SPRAY POLYURETHANE
FOAM (1"[25 mm]
MIN. THICKNESS

SHEET METAL
SCUPPER LINER
ROOF DECK
PREPARE AS
REQUIRED

PARAPET WALL .

PRIMARY DRAINAGE SCUPPER AT PARAPET WALL

2001

NOT DRAWN TO SCALE

SPF- 21B